


VUE MOTEUR 1P65F



ITEM	REFERENCE	DESCRIPTION FR	DESCRIPTION UK	REF USINE	QTE PAR PRODUIT
1	JLGB578786	BOULON M6X45	Bolt M8x50	GB5787-86	7
2	JLGB987718822X35X7	JOINT SPY 22X38X7	Oil Seal 25X40X7	GB9877.1-88	1
3	JL600105	COUVERCLE MOTEUR	Crankshaft Cover	JL60.01-05	1
4	GABT430124	AXE DE CENTRAGE	Positioning pin 9X14	GB119	2
5	JL600012	PLAQUE FIXATION REGULATEUR	Speed sets of gear shaft platen	JL60.00-12	1
6	JLGB578786	BOULON M6X45	Bolt M6x12	GB5787-86	1
7	JL600702	PIGNON DE REGULATEUR	Speed Gear	JL60.07-02	1
8	JL600724	JOINT 6.5X15X0.5	Gasket 6.5X15X0.5	JL60.07-24	1
9	JLGB97285	Rondelle	Gasket 6.2x12x1	GB97.2-85	1
10	JL600716	PIECE	Kits	JL60.07-16	1
11	JL600717	AXE	Speed gear shaft	JL60.07-17	1
12	JL60011	JOINT	Paper Pad	JL60.01-1	1
13	JL600501	ARBRE A CAME	Camshaft	JL60.05-01	1
14	JL60053	POUSSOIR	Tappet	JL60.05-3	1
15	JL600401	VILEBREQUIN	Crankshaft	JL60.04-01	1
16	JL600301	BIELLE	Connecting rod assembly	JL60.03-01	1
17	JL65032	SEGMENT DE FEU	Piston ring I	JL65.03-2	1
18	JL65033	SEGMENT INTERMEDIAIRE	Piston ring II	JL65.03-3	1
19	JL650310	SEGMENT DE GUIDAGE	Guide way	JL65.03-10	2
20	JL65039	SEGMENT RACLEUR	Oil ring scratch tablets	JL65.03-9	1
21	JL65031	PISTON	Pistons	JL65.03-1	1
22	JL60034	CERCLIPS DE PISTON	Spring piston pin	JL60.03-4	2
23	JL60035	AXE DE PISTON	Piston Pin	JL60.03-5	1
24	JL600001	JAUGE A HUILE cf GHK450120	Oil-foot assembly	JL60.00-01	1
25	JLGB578786	BOULON M6X45	Bolt M6X45	GB5787-86	1
26	JL600017	PIECE	Oil feet separated sets	JL60.00-17	1
27	JL6007022	PLAQUE	Control board	JL60.07-02.2	1
28	JLGB578986M6X18	VIS M6X18	Bolt M6x18	GB5789-86M6X18	2
29	JL6011012	AXE BOULON M6X95	Double head step stud bolt M6X92	JL60.11-01.2	2
30	JLGB617786	ECROU DE VOLANT M14X1.5	nut M6	GB6177-86	1

ITEM	REFERENCE	DESCRIPTION FR	DESCRIPTION UK	REF USINE	QTE PAR PRODUIT
31	JL6007108	LEVIER REGULATEUR	Speed Rocker	JL60.07.108	1
32	JL600725	PIECE	T-Bolt	JL60.07-25	1
33	JL60006	TUBE RENIFLAR	Exhaust Pipe	JL60.00-6	1
34	JL60073	PIECE DE LIAISON	Speed Swing Link	JL60.07-3	1
35	JLGB97285	Rondelle	Gasket 6.2x12x1	GB97.2-85	1
36	JLGB987718822X35X7	JOINT SPY 22X38X7	Oil Seal 6X11X4	GB9877.1-88	1
37	JLQ06077	PIECE	Sales openings	Q06.07-7	1
38	JLGB617786	ECROU DE VOLANT M14X1.5	Nut M6	GB6177-86	2
39	JLGB578786	BOULON M6X45	Bolt M6x12	GB5787-86	2
40	JL6013001	SUPPORT DROIT DE RESERVOIR	Fuel tank left support	JL60.13-00.1	1
41	JL60064	CERFLEX	Tubing Spring II	JL60.06-4	1
42	JL65061	TUBE	Tubing	JL65.06-1	1
43	JL60062A	ANNEAU	Tubing folder	JL60.06-2A	1
44	JL60063	TUBE	Tubing Spring I	JL60.06-3	1
45	JLQ060502	FILTRE ESSENCE	Gasoline filter	Q06.05-02	1
46	JLGB578786	BOULON M6X45	Bolt M6x12	GB5787-86	2
47	JLGB578786	BOULON M6X45	Bolt M6x20	GB5787-86	1
48	JL601300A	RESERVOIR	Fuel Tank	JL60.13-00A	1
49	JL601004A	PIECE	Tank stent	JL60.10-04A	1
50	JLGB578786	BOULON M6X45	Bolt M6x12	GB5787-86	1
51	JL6013002	SUPPORT GAUCHE DE RESERVOIR	Fuel tank right support	JL60.13-00.2	1
52	JL60014	FILTRE A HUILE	Oil Filter	JL60.01-4	1
53	JL60013	CLAPET	Ventilator paper pad	JL60.01-3	1
54	JL60012	MECANIQUE DE VENTILATION	Mechanical ventilation valve	JL60.01-2	1
55	JL600102	VALVE	Ventilator covered	JL60.01-02	1
56	JLGB578786	BOULON M6X45	Bolt M6x12	GB5787-86	2
57	JL601001	VOLANT	Flywheel	JL60.10-01	1
58	JL60101	VENTILATEUR	Fans	JL60.10-1	1
59	JL601202A	BOL LANCEUR	Starting Hub	JL60.12-02A	1
60	JLGB617786	ECROU DE VOLANT M14X1.5	Nut M14X1.5	GB6177-86	1
61	JL601203B	COUVERCLE DE MOTEUR	The fan cover	JL60.12-03B	1
62	JL601204A	LANCEUR COMPLET MOTEUR 139T	Starting HVAC NRK	JL60.12-04A	1
63	JLGB617786	ECROU DE VOLANT M14X1.5	Nut M6	GB6177-86	3
64	JL601213B	CAPOT MOTEUR	Starting cover	JL60.12-13B	1
65	GLNGP46T49	VIS VOIR JLGB8458542X16	Screw ST4.2X16	GB845-85	4
66	JLGB578786	BOULON M6X45	Bolt M6x20	GB5787-86	1
67	JL601104	INTERRUPTEUR	Off switch	JL60.11-04	1
68	JLGB578786	BOULON M6X45	Bolt M6x12	GB5787-86	1
69	JL600705	SUPPORT DE FREIN	Brake bodies	JL60.07-05	1
70	JL601105C	CABLE D ARRET	Off line	JL60.11-05C	1
71	JLGB987718822X35X7	JOINT SPY 22X38X7	Oil Seal 25X38X7	GB9877.1-88	1
72	JLGB6205	ROULEMENT 6205	Bearing 6205	GB6205	1
73	JLGB578786	BOULON M6X45	Bolt M6x25	GB5787-86	2
74	JL601101	BOBINE ALLUMAGE	Igniter	JL60.11-01	1
75	JL601213A1	PIECE	Lead a breeze cover Bushing	JL60.12-13A.1	3
76	JL6011011	GOUJONS M6X95	Double head step stud bolt M6X92	JL60.11-01.1	1
77	JL6001041	CARTER MOTEUR	Crankcase	JL60.01-04.1	1
78	JL60008	JOINT	Cylinder head gaskets	JL60.00-8	1
79	JL600011	PION 10X16	Positioning pin 10X16	JL60.00-11	2
80	JL60052	SOUPAPE D ECHAPPEMENT	Exhaust Valve	JL60.05-2	1
81	JL60051	SOUPAPE D ADMISSION	Intake valve	JL60.05-1	1
82	JL600201	CULASSE	Cylinder head	JL60.02-01	1
83	JL601103	BOUGIE	Spark Plug	JL60.11-03	1
84	JLGB90088	GOUJEON M6X95	Double-headed bolts M6X95	GB900-88	1
85	JL60007	JOINT D ECHAPPEMENT	Muffler gaskets	JL60.00-7	1
86	JL600901B	POT D ECHAPPEMENT	Muffler	JL60.09-01B	1
87	JL600902B	PROTECTEUR D ECHAPPEMENT	Muffler guards	JL60.09-02B	1
88	JLGB618786	ECROU M6	Nut M6	GB6187-86/M6	2
89	JL600801	SUPPORT DE FILTRE A AIR	Air filter base	JL60.08-01	1
90	JL6008011	BOUCHON ENTRETOISE	Air filter Bushing	JL60.08-01.1	2
91	JL600812	LEVIER	Air filter blocks oil plank	JL60.08-12	1
92	JLGB617786	ECROU DE VOLANT M14X1.5	Nut M6	GB6177-86	2
93	JL600810	FILTRE PAPIER	Air filter filterable paper	JL60.08-10	1
94	JL60085	COUVERCLE DE FILTRE	air filter cover	JL60.08-5	1
95	JL6506005	CERCLIPS	Lock tight washer	JL65.06-00.5	1
96	JL6506002	SUPPORT DE BULBE	Valve base	JL65.06-00.2	1
97	JL6506006	BULBE	primer Pipe	JL65.06-00.6	1
98	JL6506003	ANNEAU DE MAINTIEN DU BULBE	Primer clip	JL65.06-00.3	1
99	JL6506004	DURITE	PRESSURE VALVE	JL65.06-00.4	1

ITEM	REFERENCE	DESCRIPTION FR	DESCRIPTION UK	REF USINE	QTE PAR PRODUIT
100	JLGB5789868X45	BOULON 8X45	Bolt M8x45	GB5789-86-8X45	4
101	JL600503	POUSSOIR DE SOUPE	Valve Putter	JL60.05-03	2
102	JL600510	BASCULEUR	Putter guide plate	JL60.05-10	1
103	JL60054	RESSORT SOUPE	Valve Spring	JL60.05-4	1
104	JL60055	BLOCAGE DE RESSORT	Valve Spring Block	JL60.05-5	2
105	JL60057	BASCULEUR SOUPAPES	Rocker double-headed bolts	JL60.05-7	2
106	JL60056	BASCULEUR DE SOUPE	Valve Rocker	JL60.05-6	2
107	JL60058	ECROU DE REGLAGE DE SOUPE	Valve adjustment nut	JL60.05-8	2
108	JLQ030421	ECROU FREIN	Locking Nut	Q03.04-21	2
109	JL60022	JOINT cf GHK45088	Cylinder gaskets ailing	JL60.02-2	1
110	JL60021	COUVERCLE CULBUTEURS	Cylinder ailing	JL60.02-1	1
111	PGB5787	BOULON M8X45	Bolt M6x14	GB5787	4
112	JL60028	GOIJONS CARBURATEUR M6X95	Double-headed bolts M6X95	JL60.02-8	2
113	JL60005	JOINT PAPIER	Carburetor paper pad I	JL60.00-5	1
114	JL60004	BRIDE D ADMISSION	Intake manifold	JL60.00-4	1
115	JL600019	JOINT PAPIER	Carburetor paper pad II	JL60.00-19	1
116	JL60061A	CARBURATEUR	Carburetor	JL60.06-1A	1
117	JL600002	JOINT FILTRE A AIR	Air filter gaskets	JL60.00-02	1
118	JL6007109	RESSORT D'ACCÉLÉRATEUR	Throttle spring	JL60.07.109	1
119	JL6007106	TIGE STARTER	Throttle Putter	JL60.07.106	1
120	JL60075	RESSORT	gun spring	JL60.07-5	1
		maj090114			